

# **Great Moisture Barrier**

- Great for Use Over Any Existing Bottom Paint
- Anticorrosive Properties
- Adhesion Promoter
- No Overcoat Window



# **1277**Barrier Coat Primer Chorinated Rubber-





# **Product Description**

Cholorinated rubber based primer recommended for use over previous copper based antifoulants prior to recoating to insure excellent adhesion. High build, corrosion resistant, for use on new or old metal and fiberglass substrates.

## **Benefits VS. Competition**

- Compatible Over Existing Antifoulants
- No Other Comparable Product on the Market
- No Overcoat Window
- Best Adhesion Promoter in the industry

# **Product Information**

Colors: Yellow

Finish/Sheen: Flat

**Converter:** One Pack

Copper Content: N/A

Voume Solids:  $31\% (\pm 2\%)$ 

**Solids by Weight:** 

Mix Ratio: One Pack

**Shipping Weight:** 10.29 Lbs./Gal.

Flash Point: 80°F

**VOC:** 594 Grams/Liter

**Film Thickness:** 2 mils wet

**Recommended Coats:** 1

**Theoretical Coverage:** 802 Sq.Ft./Gl @ recommended film

thickness

**Application Details** 

**Method:** Brush, Roller or Spray

**Induction Time:** Not Applicable

Thinner: Sea Hawk 2044

Cleaner: Sea Hawk 2044

Pot Life: Not Applicable

# **Overcoating Interval**

Drying time in Hours

Substrate Temp. Touch Min. Max. Launch

73°F (23°C) 2 Hr 1 Hr N/A 12 Hrs

May be overcoated as little as 2 hours depending on atmospheric conditions: a recommended overnight dry before applying antifoulant.

Consult your Sea Hawk Representative for the system best suited for surfaces to be protected.

Revised 03/12



#### **APPLICATION**

Apply by brush, roller or spray. Apply 6 mils wet, which will yield 2 mils dry per coat.

# **Equipment**

Brush: China Bristle

**Roller:** Solvent Resistant Roller Cover 3/8" pile smooth to medium. Prewash Roller Cover to remove loose fibers prior to use.

#### **Airless**

**Spray:** Minimum 30:1 ratio pump; 1 GPM "0.013-0.023" orifice tip; 1/4" ID high-pressure material hose; 90 PSI line pressure; 60 mesh filter.

## **Thinning**

If thinning is necessary, thin up to a maximum of 10%, with Sea Hawk 2031.

#### Cleanup

Clean all equipment immediately after use with Sea Hawk 2031. It is a good practice to periodically flush out spray equipment during the course of the day. Frequency should depend upon amount sprayed, temperature, elapsed time including delay, etc.

# **Safety**

Prior to use, obtain and consult the "Material Safety Data Sheet" of this product for health and safety information. Read and observe all precautionary notices on container labels

## **Surface Preparation**

Paint only clean, dry surfaces. Remove all grease, oil, wax, or other foreign material using SeaHawk S-80, S-90, or detergent washing. (SSPC-SPI).

**New Construction:** Dependent on yard procedures, consult your Sea Hawk Representative.

# 1277 Barrier Coat Primer Chlorinated Rubber





#### Limitations

Apply in good weather when air and surface temperatures are above 50°F (10°C). Surface temperature must be a least 50°F (10°C) above dew point. For optimum application properties, bring material to 70-80°F (21-27°C) temperature range prior to mixing and application. Unmixed material (in closed containers) should be maintained in protected storage between 40° and 100°F (4-38°C).

Prolonged atmospheric exposure of this product may detract from performance.

Technical and application data herein is for the purpose of establishing a general guideline of the coating and proper coating application procedures. As application, environmental and design factors can vary significantly due care should be exercised in the selection, verification of performance, and use of the coating.